FCA Secure Gateway access

Step-by-step guide



CONNECTING YOUR DIAGNOSTIC TOOL FOR USE WITH SECURE VEHICLE GATEWAYS

FCA vehicles from 2018 and up are equipped with the Security Gateway (SGW). The SGW works as a "firewall" to prevent security breaches on all the on-board modules.

The SGW access for the FCA vehicles in North America* is provided by AutoAuth.

What you need:

- A compatible TEXA diagnostic tool with Wi-Fi access
- An authorized AutoAuth account(s)

CREATING AN AUTOAUTH ACCOUNT

1. The AutoAuth registration can be done from the AutoAuth website (https://webapp.autoauth.com/login) or from the link provided in the TEXA IDC5 software in figure 1.

CERTIFIED B					
Enter your credentials to access the through the <i>AutoAuth</i> ™ portal:	FCA authenticated diagnosis				
Username					
Password					
To sign up or manage your account, click on the following link: www.autoauth.com					
	\sim \times				

Figure 1 - LOGIN in IDC5 software



2. Click **Register**.

	English
	User Login
	Username or Email Address
	Password
AUTOAUTH®	Forgot Password?
Providing an Independent Trust Authority for OEMs, Tools Vendors &	Resend Confirm Link
Service Shops to securely service modern vehicles	Login
	l l l l l l l l l l l l l l l l l l l
	Need an account?
	Register
	About Us Contact Us FAQ Privacy Policy Cookies Policy Refund/Cancelation Policy W9 Form System Information

Figure 2 - Registration page

3. Complete the form with the requested information, check the Terms and Conditions box and **select Signup**. You will receive a confirmation email to validate the new account.

	English								
					User Si	ignup			
			U	ISERNAME		EMAIL			
			(Username		Email			
			F	IRST NAME		CONFIRM EMAIL			
			(First Name		Confirm Email			
AUTOAUTHENTICATION AUTHORITY			L	AST NAME		PASSWORD			
Providing an Independent Trust			(Last Name		Password			
Authority for OEMs, Tools Vendors & Service Shops to securely service						CONFIRM PASSWORD			
modern vehicles						Confirm Password			
					Terms & Conditions	ACCEPT			
					THIS SITE IS PROTECTED I	BY RECAPTCHA AND			
					THE GOOGLE PRIVACY PO SERVICE APPLY.				
					Signu	up			
							*		
	About Us	Contact Us	FAQ	Privacy Policy	Cookies Pol	elicy Refu	nd/Cancelation Policy	W9 Form	System Information

Figure 3 - New account creation



4. Login to the AutoAuth portal and select the account type to complete the registration.

AUTOAUTH	Welcome to AutoAuth/	
Area My Activity		For Service Centers & Independent Technicians If you are a Service Center owner/manager or you are an Independent Technician with your own AutoAuth Centified Diagnostic tools, click the link below to register yourself or your Service Center. Service Center Signap Independent Technician Signap
		For Technicians If you are an employee of a Service Center that is already registered in the AutolAuth system, inform your Service Center owner/manager of your user account username (found on the User Profile page). With your username, your Service Center owner/manager can invite you to join the Service Center. Once you are invited you will see a link on this page to join the Service Center. User PeoPle
() Support (+ Logout		






Figure 5 - Differences between accounts




5. Select Manage Tools and then Add tools.

STANDARD	Welcome to AutoAuth!	Upgrade To Standard Plus
√∿∘ My Activity	Shop TEXA USA My Role OWNER	
Manage Tools		
Manage Users	Get Started Add tools and users to your shop so you can start servicing vehicles.	+ Add User + Add Tools
View Reports PLUS Stats & Trends PLUS Shop Actions PLUS Tool Actions PLUS	Upgrade To Standard Plus Standard Plus will give you, the Owner, a log of all your past shop actions.	Upgrade Now
💥 Shop Profile		
函量 My Profile ※ New Features		
Compare Plans		
⑦ Support⇒ Logout		

Figure 6 - Add tools

6. Select TEXA from the manufacturer list.

AUTOAUTH [®] STANDARD	Manage Tools / Current Tools	Add Tool	×
My Activity	Get Started Add tools to your shop so you can start servicing vehicles.	Pick the Type of Tool NMME (0011044) Name	
Manage Users	+ Add Tool & Refresh MANUFACTURER MODEL	MAN,RACTURER None Selected To TEXA None Selected	
Stats & Trends PLUS Shop Actions PLUS Tool Actions PLUS Shop Profile		SERAL NUMBER	
* New Features		Add Tool	
Compare Plans O Support E> Logout	Previous Pc		






7. Select All models.

STANDARD	Manage Tools / Current Tools	Add Tool	×
- My Activity	Get Started Add tools to your shop so you can start servicing vehicles.	Pick the Type of Tool	
Anage Users	+ Add Tool C Refresh MANNFACTURER MODEL	Name MANUFACTURER TEXA	
View Reports PLUS Stats & Trends PLUS Shop Actions PLUS Tool Actions PLUS		TOOL MODEL None Selected SANI Models Serial Number	
Shop Profile			
🔆 New Features		Add Tool	
	Previous Pa		
Compare Plans ⑦ Support ▷ Logout			

Figure 8 - Select the Tool Model

8. Enter the tool serial number and select **Add Tool.**

STANDARD	Manage Tools / Current Tools	Add Tool	×
-Vvo My Activity	Get Started Add tools to your shop so you can start servicing vehicles.	Pick the Type of Tool NAME (OPTIONAL) Name	
Anage Users	+ Add Tool Z Refresh MANUFACTURER MODEL		
Stats & Trends Shop Actions Tool Actions Shop Profile		All Models SERIAL NUMBER DINTITIXXXXXXX	
(출) My Profile		Add Tool	
外 New Features			
Compare Plans ③ Support	Previous Pa		
() support ⇒ Logout			





9. The tool will be displayed in the tool list.

	Manage Tools / Current Tools			Upgrade To Standard Plus
-V My Activity	+ Add Tool 3 Refresh		1 of 5 Maximum Shop Tools	Columns 👻
Manage Tools	MANUFACTURER	MODEL	SERIAL NO.	ACTIONS
Manage Users	ТЕХА	All Models	DN1WTXXXXXX	① D 前
View Reports PLUS				
Stats & Trends PLUS Shop Actions PLUS Tool Actions PLUS				
Shop Profile				
A My Profile				
🔅 New Features				
	Previous		Page 1 of 1 10 rows	Next
Compare Plans ⑦ Support				
€→ Logout				

Figure 10 - Tool list

HOW TO UNLOCK THE SECURE GATEWAY WITH TEXA TOOL

10. Start the communication with the FCA vehicle using the TEXA IDC5 software

11. When the vehicle is equipped with Secure Gateway, IDC5 will notify you via a message (figure 11). Click "CLICK HERE" to proceed with entering the credentials (figure 12) issued by AutoAuth to start unlocking the vehicle.




Figure 11 - TEXA IDC5 software

COMPATIBLE DIAGNOSTIC TOOLS



COMPATIBLE DIAGNOSTIC SOFTWARE VERSIONS

You need the IDC5 CAR software to be at version V76.0.1A or newer.



AutoAuth will only provide support for problems related to product registration via their portal. For all problems with TEXA IDC5 software please contact TEXA USA



Copyright TEXA S.p.A. 04/2023 - NA - V1



TEXA USA Inc. 409 Joyce Kilmer Ave New Brunswick, NJ 08901 +1 855.200.8392 www.texausa.com northamerica@texa.com



facebook.com/texausa

instagram.com/texa_usa

https://www.youtube.com/channel/ UCeRUc40oDFoydkOO40SklqA